



**INSTALLATION INSTRUCTIONS**

- |          |  |
|----------|--|
| <b>A</b> | INSTALL RACEWAY BRACKETS USING PROVIDED (4) 8-32 3/16 SCREWS IN 4 PRE-DRILLED HOLES.     |
| <b>B</b> | SLIDE "E" BRACKET INTO RACEWAY BRACKET   |
| <b>C</b> | ATTACH "E" BRACKET TO BACK BOX USING PROVIDED (4) 8-32 3/16 SCREWS IN PRE-DRILLED HOLES. |

REVISION: 11/2019

MATERIAL :

COMPATIBLE ROUGH IN BOXES:

DESCRIPTION:

REV

ALL DIMENSIONS ARE FOR REFERENCE ONLY. ALL DIMENSIONS ARE IN INCHES

- 16ga Galvannealed Steel

102BBX / 102BBXW

Horizontal Panel Bracket Kit for Full Size 6.00" Deep Back Box. Bracket installation to support Super Pocket Body construction phase sub-assembly.

1

SHEET 1 OF 1